



WINDSOI  
WINDOWS & DOOR

# Revive Measurement Guidelines


**IMPORTANT:** Be sure to collect precise measurements in order for the product to fit correctly. Fill out unit information table on page 3.

- a) Inspect the existing window frame for squareness. Measure diagonally from corner to corner of the frame on both sides of unit. Both dimensions must not differ by more than 1/4".

**Note:** Existing frame must be square otherwise replacement unit will need modification in order to be installed correctly

- b) Measure the opening width (in inches) of the existing frame at the top, middle, and bottom of the frame (shown below). Record the smallest dimension measured.

**Note:** Verify the Jamb Pocket is  $\geq 3 \frac{1}{4}$ " (shown below).



- c) Measure the opening height (in inches) of the existing frame at the left, right, and center of the frame. Record the smallest dimension measured.

**Note:** Measure from inside of head jamb to top of sill (see left).

- d) Determine the sill angle of the existing frame. Use the Sill Angle Tool located on the following page (page 2) to assist in determining the sill angle.



# Measurement Guidelines (Continued)

## Size Limitation Chart

Type	Sill Angle (Degrees)	Glass Split	Revive Replacement Unit (Frame Size)						Existing Frame (Opening Size)			
			Min Width	Max Width	Min Height		Max Height		Min Width	Max Width	Min Height	Max Height
					Inside Frame	Outside Frame	Inside Frame	Outside Frame				
Clad DH Operating	0-7 Degree	Equal	17 3/8	47 3/8	31 29/32	31 29/32	95 29/32	95 29/32	17 7/8	47 7/8	32 9/32	96 9/32
		Cottage / Oriel	17 3/8	47 3/8	37 29/32	37 29/32	81 7/32	81 7/32	17 7/8	47 7/8	38 9/32	81 19/32
	>7 Degree	Equal	17 3/8	47 3/8	31 5/16	31 29/32	95 5/16	95 29/32	17 7/8	47 7/8	31 11/16	95 11/16
		Cottage / Oriel	17 3/8	47 3/8	37 5/16	37 29/32	80 5/8	81 7/32	17 7/8	47 7/8	37 11/16	81
Clad DH Picture	0-7 Degree	NA	16 3/4	73 3/8	19 11/16	19 11/16	76 7/16	76 7/16	17 1/4	73 7/8	20 1/16	76 13/16
	>7 Degree		16 3/4	73 3/8	19 3/32	19 11/16	75 27/32	76 7/16	17 1/4	73 7/8	19 15/32	76 7/32
Hybrid DH Operating	0-7 Degree	Equal	17 3/8	41 3/8	31 29/32	31 29/32	79 29/32	79 29/32	17 7/8	41 7/8	32 9/32	80 9/32
		Cottage / Oriel	17 3/8	41 3/8	37 29/32	37 29/32	67 29/32	67 29/32	17 7/8	41 7/8	38 9/32	68 9/32
	>7 Degree	Equal	17 3/8	41 3/8	31 5/16	31 29/32	79 5/16	79 29/32	17 7/8	41 7/8	31 11/16	79 11/16
		Cottage / Oriel	17 3/8	41 3/8	37 5/16	37 29/32	67 5/16	67 29/32	17 7/8	41 7/8	37 11/16	67 11/16
Hybrid DH Picture	0-7 Degree	NA	16 3/4	61 3/8	20 3/16	20 3/16	75 13/16	75 13/16	17 1/4	61 7/8	20 9/16	76 3/16
	>7 Degree		16 3/4	61 3/8	19 19/32	20 3/16	75 7/32	75 13/16	17 1/4	61 7/8	19 31/32	75 19/32
Clad Pocket Casement	0-14 Degree	NA	16	42	18	18	84	84	16 1/2	42 1/2	18 3/8	84 3/8
Hybrid Pocket Casement	0-14 Degree	NA	16	36	18	18	78	78	16 1/2	36 1/2	18 3/8	78 3/8
Clad Pocket Awning	0-14 Degree	NA	18	60	18	18	60	60	18 1/2	60 1/2	18 3/8	60 3/8
Hybrid Pocket Awning	0-14 Degree	NA	18	48	18	18	36	36	18 1/2	48 1/2	18 3/8	36 3/8
Clad Pocket Csmnt Picture	0-14 Degree	NA	16	72	12	12	84	84	16 1/2	72 1/2	12 3/8	84 3/8
Hybrid Pocket Csmnt Picture	0-14 Degree	NA	16	72	12	12	78	78	16 1/2	72 1/2	12 3/8	78 3/8
Vinyl Casement	0-14 Degree	NA	15 1/2	35 1/2	17 1/2	17 1/2	71 1/2	71 1/2	16	36	17 7/8	71 7/8
Vinyl Casement Picture	0-14 Degree	NA	15 1/2	95 1/2	11 1/2	11 1/2	95 1/2	95 1/2	16	96	11 7/8	95 7/8
Vinyl SH Operating	0-14 Degree	Equal	13 1/2	47 1/2	23 1/2	23 1/2	83 1/2	83 1/2	14	48	23 7/8	83 7/8
		Cottage / Oriel	13 1/2	47 1/2	23 1/2	23 1/2	83 1/2	83 1/2	14	48	23 7/8	83 7/8
Vinyl SH Picture	0-14 Degree	NA	13 1/2	95 1/2	11 1/2	11 1/2	95 1/2	95 1/2	14	96	11 7/8	95 7/8
Vinyl DH Operating	0-14 Degree	Equal	17 1/2	47 1/2	23 1/2	23 1/2	81 1/2	81 1/2	18	48	23 7/8	81 7/8
		Cottage / Oriel	17 1/2	47 1/2	23 1/2	23 1/2	71 1/2	71 1/2	18	48	23 7/8	71 7/8
Vinyl DH Picture	0-14 Degree	NA	11 1/2	95 1/2	11 1/2	11 1/2	95 1/2	95 1/2	12	96	11 7/8	95 7/8

Measure Existing Frame Sill Angle – Use the below template instructions to determine existing frame sill angle.

14°	13°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1°
-----	-----	-----	-----	-----	----	----	----	----	----	----	----	----	----

**Sill Angle Measuring Template**

1. Cut template along dotted lines

2. Fold template to the projected sill angle

3. Place folded edge along sill, allowing template side edge to sit against interior stops

4. Repeat Steps 2-3 until template edges are flush with sill and interior stop

**FRAME INTERIOR**



# Measurement Guidelines (Continued)

**IMPORTANT:** Be sure to collect precise measurements in order for the product to fit correctly. Fill out unit information table on following page.

Existing Window Measurement Log				
#	Window Location/Room	Opening Width (Step B, page 1)	Opening Height (Step C, page 1)	Sill Angle (Step D, page 1)
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				

Additional Notes: